



GUANGZHOU HAWKS AUTOPARTS CO.,LTD

No.8 Xicheng Road,Renhe Town,Baiyun District, Guangzhou City, Guangdong Province

Web:www.hawksparts.com E-mail:sales@hawksparts.com

Contact person:Hawks Sale Team Mob:+86 18027472559

Cummins 6BT Parts Catalogue

Part Number	Part Name	Part Number	Part Name
3966454	Cylinder Head	3928797	Cylinder Block
3907163	Piston	3929037	Crankshaft
3926631	Piston	3942581	Connecting Rod
3283576	Injector	3283562	Injector
3900709	Oil Seal	3925529	Oil Seal
3918188	Washer Sealing	3907617	Push Rod
3910260	O Ring Seal	3914086	Belt Tensioner
3924026	Belt Tensioner	3914463	Fan Pulley
3918109	Screw	3920781	Screw
3977274	Screw	3920780	Screw
3920779	Screw	3900632	Screw
3900631	Screw	3904217	Screw
3918675	Gear Housing Cover	3920218	High Pressure Pipe
3922886	Oil Dipstick	3960410	Flywheel Housing
3931382	Fuel Pump Gear	3932520	Oil Piston Ring
3919053	Piston Pin	3938156	Gear Housing Gasket
3957544	Oil Cooler Core	3957912	Oil Seal
3958258	Vibration Damper	3960317	Oil Cooler Core Gasket
3960678	Air Compressor OI Return Pipe	3963983	Sealing Washer
3967251	Oil Pressure Sensor	3972529	Alternator
3974548	Air Compressor	4051323/4051051/4051052	Turbocharger
3976797	Combination Hose	3960623/3960519	Gear Housing

3967252	Speed Sensor	3934920/3910810/3910811	Rocker Arm
3937214	Piston Cooling Nozzle	3999603	Flywheel
3883284	O Ring Seal	3903380	Connector Gasket
3900068	Dowel Ring	81V46—04100	Air-conditioning Compressor
3941476	Bushing	3937706	Oil Pipe Gasket
3921394	Cylinder Head Gasket	3918673	Gear Housing Gasket
3959052	Oil Pan Gasket	37V66-01010	Atemator
3901356	Turbocharger Gasket	3904679	Push Rod
3900629	Screw	3938152	Gasket
329881/3905441	Gasket	3906698	Seal Ring
4934217/3913967	Oil Cooler Core Seat	3906660/4988353	Exhaust Manifold
3927772/3978822	Crankshaft Thrust Bearing	3901895	Filler Cap
FS1280/3930942	Fuel Filter	3931623	Tappet
3913994	O Ring Seal	3900956	Expansion Plug
3910248	Plastic Plug	3904166	Cylinder Liner
3903384	Piston Ring	3901117	Intake Valve
3901607	Exhaust Valve	3901258/3929027	Crankshaft Gear
3901150	Crankshaft Bearing	3931063/FF5052	Fuel Filter
3901090	Crankshaft Main Bearing	10N20-01014/10N20-01013	Front Suspension Bracket
3960061	Gear Housing Gasket	3900633	Screw
3903924	Timing Pin	3907431	Camshaft Gear
3916691	Valve Spring	3900299	Valve Spring Seat
3900250	Valve Lock	3909356	Seal Ring
3960076	Fan Bracket	3910495	Screw
3924148	Screw	3037236	O Ring Seal
3069053	V Clamp	3834N-010	Speed Sensor
3902666	Valve Chamber Cover Gasket	3960372/3960373	Chamber House Cover
3914462	Fan Pulley	1306R2-010-B2/4930315	Thermostat

3960078
3901306

Thermostat Seat
Camshaft Bushing

3901170
3960342

Connecting Rod Bearing
Water Pump