

**GUANGZHOU HAWKS AUTOPARTS CO.,LTD**

No.8 Xicheng Road,Renhe Town,Baiyun District, Guangzhou City, Guangdong Province

[Web:www.hawksparts.com](http://www.hawksparts.com) [E-mail:sales@hawksparts.com](mailto:sales@hawksparts.com)[Contact person:Hawks Sale Team](mailto:sales@hawksparts.com) [Mob:+86 18027472559](tel:+8618027472559)**Cummins KTA50 QSK50 Overhual Parts**

No.	Cummins KTA50 and QSK50 Overhaul Gasket Sets Components	Part No.
1	UPPER ENGINE GASKET SET – KTA50 / QSK50	4376343
2	UPPER ENGINE GASKET SET – KTA50 / KTTA50	4352581
3	UPPER ENGINE GASKET SET – KTA50 / KTTA50	3800731
4	LOWER ENGINE GASKET SET – QSK50	3804300
5	OIL PAN GASKET – KTA50 / QSK50	3043213
6	OIL PAN GASKET – KTA38 / KTA50 / QSK38 / QSK50	3043211
7	OIL PAN GASKET – KTA38 / QSK38 / KTA50 / QSK50	3043214
	Cummins KTA50 and QSK50 Turbochargers	
8	TURBOCHARGER – QSK50	2882102
9	TURBOCHARGER KIT – KTA50 / QSK50	2882096
10	TURBOCHARGER – QSK50 (HX80)	4955509
11	TURBOCHARGER – QSK50 (HC5A)	3801846
12	TURBOCHARGER – QSK50 (HC5A)	3801886
13	TURBOCHARGER – QSK50 (HC5A)	3801843
14	TURBOCHARGER – QSK50 (BROWN BOVERI)	3801698
15	TURBOCHARGER – QSK50 (BROWN BOVERI)	3801564
16	TURBOCHARGER KIT – QSK50 (TIER 2, MARINE)	4955667
17	TURBOCHARGER – QSK50 (HX82, DRY)	4955353
18	TURBOCHARGER – KTA50 (HX80)	4090027
19	TURBOCHARGER KIT – KTA50 / QSK50	2881768
	Cummins KTA50 and QSK50 Cylinder Head Gaskets	
20	CYLINDER HEAD GASKET SET – KTA38 / QSK38 / QSK50 (SINGLE)	4352579
21	CYLINDER HEAD GASKET SET – KTA50 / QSK50 (SINGLE)	4352588
22	CYLINDER HEAD – KTA50 / QSK50	3649935
23	CYLINDER HEAD GASKET – KTA19 / KTA38 / KTA50 / QSK19	3634664
24	CYLINDER HEAD GASKET – KTA19 / KTA38 / KTA50 / QSK19	3166288
25	CYLINDER HEAD GASKET SET – KTA50 / QSK50	3801897
26	CYLINDER HEAD GASKET SET – QSK50	4956034
27	CYLINDER HEAD GASKET SET – KTA50 / QSK50 (QUADRANT)	4352589

Cummins KTA50 and QSK50 Valve Train Components		
28	EXHAUST VALVE KIT – KTA19 / KTA38 / KTA50 / QSK19	3803528
29	EXHAUST VALVE INSERT – KTA19 / KTA38 / KTA50	205093
30	INTAKE VALVE SEAT INSERT – KTA19 / KTA38 / KTA50	3052819
31	INTAKE VALVE SEAT INSERT – KTA19 / QSK19 / QSK38	3026296
32	INTAKE VALVE – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	3803515
33	EXHAUST VALVE KIT – KTA19 / KTA38 / KTA50 / QSK19	3803529
34	ROCKER LEVER – KTA38 / QSK38 / KTA50 / QSK50	3053479
35	PUSH ROD – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	3017961
36	CAM FOLLOWER LEVER – KTA19 / QSK19 / KTA38 / QSK38	3039163
37	INTAKE VALVE SEAT INSERT – KTA19 / KTA38 / KTA50	3031098
38	INTAKE VALVE KIT – KTA19 / KTA38 / KTA50	3803518
39	CAM FOLLOWER LEVER – KTA19 / QSK19 / KTA38 / QSK38	3039164
40	CAM FOLLOWER LEVER – KTA19 / QSK19 / KTA38 / QSK38	3642503
41	INTAKE VALVE KIT – KTA19 / QSK19 / KTA38 / QSK38	2881836
42	ROCKER LEVER – KTA19 / QSK19 / KTA38 / QSK38 / KTA50	3053477
43	INTAKE VALVE SEAT INSERT – KTA50 / QSK50 / KTA19	3086193
44	EXHAUST VALVE KIT – KTA19 / KTA38 / KTA50 / QSK19	4955286
Cummins KTA50 and QSK50 Water Pumps		
45	RAW WATER PUMP – KTA38 / KTA50 / QSK38 / QSK50	4078936
46	RAW WATER PUMP – KTA38 / KTA50 / QSK38 / QSK50	3897387
47	RAW WATER PUMP – KTA38 / KTA50 / QSK38 / QSK50	3897791
48	RAW WATER PUMP KIT – QSK38 / QSK50 / QSK60	4955947
49	WATER PUMP – KTA38 / QSK38 / QSK50	3647140
50	RAW WATER PUMP – KTA38 / QSK38 / QSK50	4314522
51	RAW WATER PUMP – KTA38 / KTA50 / QSK38 / QSK50 (GILKES)	3085649
52	WATER PUMP KIT – G50 / K50 / QSK50	4376118
53	RAW WATER PUMP – KTA38 / QSK38 / QSK50	4376151
Cummins KTA50 and QSK50 Thermostats		
54	THERMOSTAT – KTA38 / QSK38 / QSK45 / QSK50 / QSK60	3055663
55	THERMOSTAT	3349225
56	THERMOSTAT – KTA / QSK (176°F, NON VENTED)	3629205
57	REGULATOR – KTA38 / QSK38 / QSK45 / QSK50 / QSK60	3639983
Cummins KTA50 and QSK50 Repair Kits		

58	WATER PUMP REPAIR KIT – KTA38 / KTA50 / QSK38 / QSK45	4085922
59	RAW WATER PUMP REPAIR KIT – KTA19 / KTA38 (MAJOR)	3897385
60	RAW WATER PUMP REPAIR KIT – KTA19 / KTA38 / KTA50 (MAJOR)	3866065
61	RAW WATER PUMP REPAIR KIT – KTA38 / KTA50 / QSK38 / QSK50	4334439
62	RAW WATER PUMP REPAIR KIT – KTA38 / QSK38 / QSK50	4334440
63	RAW WATER PUMP REPAIR KIT – KTA38 / QSK38 / QSK50	4334438
	Cummins KTA50 and QSK50 Heat Exchangers	
64	HEAT EXCHANGER PLATE – KTA38 / KTA50 / QSK38 / QSK50	5254020
65	HEAT EXCHANGER PLATE – KTA38 / KTA50 / QSK38 / QSK50	5254021
66	HEAT EXCHANGER PLATE GASKET – KTA38 / KTA50 (LOOSE)	4078967
67	HEAT EXCHANGER PLATE – KTA38 / KTA50 / QSK38 / QSK50	4078963
68	HEAT EXCHANGER PLATE – KTA38 / KTA50 / QSK38 / QSK50	4078961
69	HEAT EXCHANGER GASKET – KTA38 / KTA50 / QSK38 / QSK50	4078971
70	HEAT EXCHANGER – KTA50 / QSK38 / QSK50	5254017
71	HEAT EXCHANGER – KTA50	4964505
72	HEAT EXCHANGER – QSK50	4964507
73	HEAT EXCHANGER PLATE – KTA38 / KTA50 / QSK38 / QSK50	3969454
74	HEAT EXCHANGER PLATE – KTA38 / KTA50 / QSK38 / QSK50	3969455
75	HEAT EXCHANGER PLATE – KTA38 / KTA50 / QSK38 / QSK50	4078962
76	HEAT EXCHANGER PLATE – KTA38 / KTA50 / QSK38 / QSK50	4078966
77	HEAT EXCHANGER PLATE – QSK 38 / QSK50 (B-PLATE)	4998572
78	HEAT EXCHANGER PLATE – QSK 38 / QSK50 (B-PLATE)	4998570
79	HEAT EXCHANGER PLATE – QSK 38 / QSK50 (A-PLATE)	4998571
80	HEAT EXCHANGER PLATE – QSK 38 / QSK50 (A-PLATE)	4998573
81	HEAT EXCHANGER PLATE – QSK 38 / QSK50 (A-PLATE)	4998565
82	HEAT EXCHANGER PLATE – QSK 38 / QSK50 (A-PLATE)	4998567
83	HEAT EXCHANGER PLATE – QSK 38 / QSK50 (A-PLATE)	4998569
	Cummins KTA50 and QSK50 Fuel Injectors	
84	FUEL INJECTOR – G50 / K50 / QSK50 (PT TYPE D)	3053126
85	FUEL INJECTOR – KTA38 / KTA50 / QSK19 / QSK38 / QSK50	2882078
86	FUEL INJECTOR – KTA50 / QSK50	4950431
87	FUEL INJECTOR – KTA38 / KTA50 / QSK19 / QSK38 / QSK50	2882077
	Cummins KTA50 and QSK50 Fuel Filters	
88	FUEL/WATER SEPARATOR FILTER (SPIN-ON)	FS1006

89	FUEL FILTER (SPIN-ON)	FF202
90	FUEL FILTER	FF5644
91	FUEL/WATER SEPARATOR FILTER	FS19870
	Cummins KTA50 and QSK50 Camshaft Components	
92	CAMSHAFT BUSHING – KTA38 / KTA50 / QSK38 / QSK50	205230
93	REMANUFACTURED CAMSHAFT – KTA50 / QSK50 (RIGHT BANK)	3074304
94	REMANUFACTURED CAMSHAFT – KTA50 / QSK50 (LEFT BANK)	3074305
95	REMANUFACTURED CAMSHAFT – KTA50 / QSK50	3066907
96	REMANUFACTURED CAMSHAFT – KTA50 / QSK50	3066906
97	REMANUFACTURED CAMSHAFT – KTA50 / QSK50	3066897
98	REMANUFACTURED CAMSHAFT – KTA50 / QSK50	3066896
99	REMANUFACTURED CAMSHAFT – KTA50 / QSK50	3066895
100	REMANUFACTURED CAMSHAFT – KTA50 / QSK50 (LEFT BANK)	3066894
101	CAMSHAFT THRUST BEARING	3007971
102	CAMSHAFT – KTA50 / QSK50	3098596
103	CAMSHAFT – KTA50 / QSK50	3098597
104	CAMSHAFT – KTA50 / QSK50	3076764
105	CAMSHAFT – KTA50 / QSK50 (RIGHT BANK)	3076765
106	CAMSHAFT – KTA50 / QSK50	3076766
107	CAMSHAFT – KTA50 / QSK50	3076763
108	CAMSHAFT – KTA50 / QSK50	3066898
109	CAMSHAFT – KTA50 / QSK50	3066899
110	CAMSHAFT – KTA50 / QSK50	3062622
111	CAMSHAFT – KTA50 / QSK50	3098738
112	CAMSHAFT – KTA50 / QSK50	3098739
113	CAMSHAFT BUSHING – KTA38 / QSK38 / KTA50 / QSK50	3175805
114	CAMSHAFT – KTA50 / QSK50	3096933
115	CAMSHAFT – KTA50 / QSK50	3096934
116	CAMSHAFT – KTA50 / QSK50	3641071
117	CAMSHAFT – KTA50 / QSK50	3641072
	Cummins KTA50 and QSK50 Piston Kits	
118	PISTON KIT – KTA50 / QSK50	4309216
119	PISTON KIT – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	3631245
120	PISTON KIT – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	3631246

121	PISTON KIT – QSK50 (WITH OFFSET PIN AND RETAINERS)	3804885
122	PISTON BODY – KTA38 / QSK38 / KTA19 / QSK19 / KTA50	3096680
123	PISTON KIT – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	4090013
124	PISTON KIT – KTA38 / KTA50 / QSK38 / QSK50	3804747
	Cummins KTA50 and QSK50 Piston Ring Sets	
125	PISTON RING SET – KTA19 / QSK19 / QSK50 / QSK60 / QSK95	4309503
126	PISTON RING SET – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	2865146
127	PISTON RING SET – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	4955976
128	PISTON RING SET – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	4090028
129	PISTON RING SET – KTA19 / QSK19 / QSK50	4352282
	Cummins KTA50 and QSK50 Connecting Rod Bearings	
130	CONNECTING ROD BEARING – KTA38 / QSK38 (STANDARD)	3047390
131	CONNECTING ROD – KTA38 / QSK38 / QSK50	3632411
132	CONNECTING ROD SHELL – KTA38 / QSK38 / QSK50 (.030)	3047393
	Cummins KTA50 and QSK50 Liners and Liner Kits	
133	CYLINDER LINER KIT – KTA38 / KTA50 / QSK38 / QSK50	3007525
134	CYLINDER LINER – KTA38 / KTA50 / QSK38 / QSK50 (STANDARD)	3022157
135	CYLINDER LINER KIT – KTA38 / KTA50 / QSK38 / QSK50 (.010)	3023017
136	CYLINDER LINER KIT – KTA38 / KTA50 / QSK38 / QSK50	4955328
137	CYLINDER LINER KIT – KTA38 / KTA50 / QSK38 / QSK50 (.020)	3023018
138	CYLINDER LINER KIT – KTA19 / KTA38 / QSK19 / QSK38	3801268
139	CYLINDER LINER INSERT – KTA38 / QSK38 / KTA50	3021148
140	CYLINDER LINER INSERT – KTA38 / QSK38 (.1995 IN)	3011884
	Cummins KTA50 and QSK50 Crankshafts	
141	CRANKSHAFT – KTA50 / QSK50	3648634
142	CRANKSHAFT – QSK50	3648618
143	CRANKSHAFT – KTA50 / QSK50	4098998
144	CRANKSHAFT – QSK50	4099000
	Cummins KTA50 and QSK50 Crankshaft Bearings and Seals	
145	MAIN BEARING SET – KTA19 / KTA38 / KTA50 / QSK19	AR12250
146	MAIN BEARING SET – KTA38 / QSK38 / QSK50 (STANDARD)	3018210
147	REAR OIL SEAL – (WET DOUBLE LIP)	3005887
148	MAIN BEARING SET – KTA38 / QSK38 / QSK50 (.010)	3018211
149	MAIN BEARING SET – KTA38 / QSK38 / QSK50 (.020)	3018212

150	OIL SEAL – G28 / K50 / KTA38 / QSK38 / QSK50 / V28	3076066
151	FRONT CRANKSHAFT SEAL KIT – KTA38 / KTA50 / QSK38 / QSK50	3803994
152	REAR CRANKSHAFT OIL SEAL – KTA38 / QSK38 / KTA50 / QSK50	3070080
	Cummins KTA50 and QSK50 Vibration Dampers	
153	VIBRATION DAMPER – QSK50 (VISCOUS)	3628649
154	VIBRATION DAMPER – KTA50 / QSK38 / QSK50 / QSK60	3089627
155	VIBRATION DAMPER – QSK50 (VISCOUS)	3628651
156	VIBRATION DAMPER – KTA38 / QSK38 / QSK50 (VISCOUS)	3628650
	Cummins KTA50 and QSK50 Belts	
157	BELT TENSIONER – KTA38 / QSK38 / QSK50	3691279
158	BELT TENSIONER – KTA38 / QSK38 / QSK50	5333497
159	RIBBED V-BELT – KTA38 / KTA50 / QSK38 / QSK50	3644380
160	RIBBED V-BELT – KTA38 / KTA50 / QSK38 / QSK50	5413003
161	RIBBED V-BELT – KTA50 / QSK50	5413024
162	RIBBED V-BELT – KTA50 / QSK50	5413027
163	BELT – K38 / KTA50 / QSK38 / QSK45 / QSK45G / QSK50	5413029
164	V-BELT – GTA38 / K38 / KTA38GC / QSK38	178456
165	V-BELT – K19 / KTA19/QSK19 / KTA19GC / QSK19	178568
166	ENGINE BELT – G28 / V28 / G50 / K50	191502
167	RIBBED V-BELT – KTA38 / KTA50 / QSK38 / QSK50 / QST30	5413022
168	V RIBBED BELT – G50 / GTA38 / K38 / K50 (23 RIBS)	5413001
169	V RIBBED BELT – KTA38GC / QSK38	5466992
170	RIBBED V-BELT – KTA50 / QSK50	3179673
171	RIBBED V-BELT – KTA50 / QSK50	3179675
172	RIBBED V-BELT – KTA38 / KTA50 / QSK38 / QSK50 / QST30	3176459
173	RIBBED V-BELT – KTA50 / QSK50	3632383
174	RIBBED V-BELT – KTA38 / KTA50 / QSK38 / QSK50	3644379
175	RIBBED V-BELT – KTA38 / KTA50 / QSK38 / QSK50	3632788
176	BELT – K38 / K50	3039376
177	ALTERNATOR BELT – GTA38 / K38 / KTA38GC / QSK38	178567
	Cummins KTA50 and QSK50 Oil Coolers	
178	OIL COOLER CORE – KTA38 / QSK38 / QSK50	3635074
179	OIL COOLER CORE – KTA38 / KTA50 / QSK38 / QSK50	3627295
180	OIL COOLER CORE – KTA50 / QSK38 / QSK50	4916621

Cummins KTA50 and QSK50 Piston Cooling Nozzles		
181	PISTON COOLING NOZZLE	3879479
182	PISTON COOLING NOZZLE – KTA38 / QSK38 / QSK50	3044464
183	PISTON COOLING NOZZLE – KTA38 / QSK38 / QSK50	4099041
184	PISTON COOLING VALVE – KTA38 / QSK38 / KTA50 / QSK50	3179664
185	PISTON COOLING NOZZLE – KTA38 / QSK38 / QSK50	3626728
186	PISTON COOLING NOZZLE – KTA38 / QSK38 / QSK50	3179664
Cummins KTA50 and QSK50 Oil Filters		
187	OIL FILTER CARTRIDGE (SPIN-ON)	LF777
188	OIL FILTER	LF9050
189	OIL FILTER (SPIN-ON)	LF3325
190	OIL FILTER	LF3363
Cummins KTA50 and QSK50 Lubricating Primers		
191	ENGINE LUBRICATING PRIMER – KTA50 / QSK38 / QSK50	3630004
192	ENGINE LUBRICATING PRIMER – KTA50 / QSK38 / QSK50	3628997
193	ENGINE LUBRICATING PRIMER – KTA50 / QSK38 / QSK50	3637969
194	ENGINE LUBRICATING PRIMER – KTA50 / QSK38 / QSK50	3628965
Cummins KTA50 and QSK50 Exhaust Manifolds		
195	EXHAUST MANIFOLD – QSK50	4302339
196	GASKET, EXHAUST MANIFOLD – KTA38 / KTA50	3037821
197	EXHAUST OUTLET PIPE – QSK50	3043032
198	EXHAUST MANIFOLD – QSK50	3028239
199	EXHAUST MANIFOLD – QSK50	3028241
200	EXHAUST MANIFOLD – QSK50	3028240
201	EXHAUST MANIFOLD – QSK50	3638159
202	EXHAUST MANIFOLD – QSK50 (DRY PULSE, BELLOWS)	3633817
203	EXHAUST MANIFOLD – KTA50 / QSK50	3630506
204	EXHAUST MANIFOLD – QSK50	3632207
205	EXHAUST MANIFOLD – QSK50	3632209
206	EXHAUST MANIFOLD – QSK50	3630952
207	EXHAUST MANIFOLD – KTA50 / QSK50	3630030
208	EXHAUST MANIFOLD – KTA50 / QSK50	3630033
209	EXHAUST MANIFOLD – QSK50	3638158
210	EXHAUST MANIFOLD – QSK50	3638160

211	EXHAUST MANIFOLD – QSK50 (DRY PULSE, BELLOWS)	3633814
212	EXHAUST MANIFOLD – QSK50 (DRY PULSE, PREMIUM BELLOWS)	3633815
213	EXHAUST MANIFOLD – QSK50 (DRY PULSE, PREMIUM BELLOWS)	3633818
214	EXHAUST MANIFOLD – QSK50 (DRY PULSE, PREMIUM BELLOWS)	3633709
215	EXHAUST MANIFOLD – QSK50 (DRY PULSE, PREMIUM BELLOWS)	3633710
216	EXHAUST MANIFOLD – QSK50 (DRY PULSE, PREMIUM BELLOWS)	3633711
217	EXHAUST MANIFOLD – QSK50	3632210
218	EXHAUST MANIFOLD – KTA50 / QSK50	3630505
219	EXHAUST MANIFOLD – KTA50 / QSK50	3630031
220	EXHAUST MANIFOLD – KTA50 / QSK50	3630032
221	EXHAUST MANIFOLD – QSK50	3630243
222	EXHAUST MANIFOLD – QSK50	3630244
223	EXHAUST MANIFOLD – QSK50	4970230
224	EXHAUST MANIFOLD – QSK50	4970229
225	EXHAUST MANIFOLD – QSK50	3640560
226	EXHAUST MANIFOLD – QSK50	3640561
	Cummins KTA50 and QSK50 Electric Starters	
227	STARTER	3651893
228	STARTER – KTA38 / QSK38 / QSK50 (DUAL ELECTRIC)	3632273
229	STARTER	3632274
	Cummins KTA50 and QSK50 Air Starters	
230	STARTER (AIR)	3026797
231	STARTER – KTA38 / KTA50 / QSK38 / QSK50 (AIR)	3037489
232	STARTER – KTA38 / KTA50 / QSK38 / QSK50 (AIR)	3634784
	Cummins KTA50 and QSK50 Alternators	
233	ALTERNATOR – KTA19 / KTA38 / KTA50 / QSK19 / QSK38	3088320
234	ALTERNATOR – KTA38 / KTA50 / QSK38 / QSK50	3640732
235	ALTERNATOR – KTA19 / KTA50 / QSK19 / QSK50	4094998
236	ALTERNATOR – ISB / ISC / ISX / QSX / KTA50 / QSK50	5282841
	Cummins KTA50 and QSK50 Senders and Switches	
237	GEAR OIL PRESSURE SENSOR	4306990
238	POSITION SENSOR – KTA19 / QSK19 / QSK60 / QSK95	4326595
239	PRESSURE SWITCH – QSK50	4328672
240	PRESSURE SWITCH – QSK50	4328673

241	POSITION SENSOR – QSK23 / QSK50 / QSK60 / QSK95	4307676
242	PRESSURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38	4927797
243	THERMOSTAT SWITCH – QSK50	3010653
244	SPEED SWITCH (24 V)	4019430
245	SPEED SWITCH – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	4003714
246	PRESSURE SWITCH – KTA19 / KTA38 / QSK19 / QSK38	4927365
247	PRESSURE SWITCH – KTA38 / QSK38 / QSK45 / QSK50	4924925
248	PRESSURE SWITCH – QSK50	3057448
249	PRESSURE SWITCH – KTA38 / QSK38 / QSK50	3628750
250	MAGNETIC SWITCH	146457
251	TEMPERATURE SENSOR – QSK50	3626875
252	TEMPERATURE SENSOR – KTA38 / QSK38 / QSK50	3408319
253	TEMPERATURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38	4903202
254	TEMPERATURE SENSOR – KTA38 / QSK38 / QSK50 / QSK60	4954491
255	TEMPERATURE SENSOR – KTA38 / QSK38 / QSK50	4954454
256	TEMPERATURE SENSOR – QSK50	4951941
257	PRESSURE SENSOR – KTA38 / QSK38 / QSK50	4954185
258	PRESSURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38	4964102
259	PRESSURE SENSOR – QSK45 / QSK50 / QSK60 / QSK95 / QST30	4088734
260	PRESSURE SENSOR – L10 / M11 / KTA19 / QSK19 / QSK60	4099173
261	PRESSURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	3408517
262	PRESSURE SENSOR – KTA38 / QSK38 / QSK50	3408651
263	PRESSURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	3408602
264	FLUID LEVEL SENSOR – KTA19 / QSK19 / QSK50 / QSV81	3096793
265	COOLANT FLUID LEVEL SENSOR – GTA38 / K38 / KTA38GC	4903016
266	SWITCH	4963952
267	TEMPERATURE SENSOR – KTA38 / QSK38 / QSK50	3633306
268	PRESSURE SENSOR	2872254
269	TEMPERATURE SENSOR – KTA38 / QSK38 / QSK50	4326918
270	POSITION SENSOR – KTA38 / QSK38 / QSK50	4307466
271	TEMPERATURE SWITCH	4327016
272	TEMPERATURE SWITCH	4327019
273	FLUID LEVEL SWITCH	4072714
274	TEMPERATURE SENSOR – QSK50 / QST30	4327199

Parts for Cummins KTA50 and QSK50 Engines		
275	LOCK NUT – KTA50 / QSK50	4380750
276	COVER PLATE GASKET – KTA38 / QSK38 / KTA50 / QSK50	3648607
277	SOLENOID VALVE – QSK50	3641305
278	PLUNGER – KTA38 / QSK38 / KTA50 / QSK50	3026927
279	FRONT GEAR COVER BUSHING – KTA38 / QSK38 / KTA50 / QSK51	3177509
280	FRONT GEAR COVER BUSHING – KTA38 / QSK38 / KTA50 / QSK50	3177510
281	SHUT-OFF SOLENOID – L10 / G50 / K50 / QSK50	3054609
282	PIN – KTA19 / QSK19 / KTA38 / QSK38 / KTA50 / QSK50	4009479
283	FLEX HOSE (TEFLON) – KTA50 / QSK50	3632018
284	VALVE COVER GASKET – QSK60 / QSK60G / K19 / KTA19	3081898
285	CONNECTION GASKET – KTA38 / QSK38 / KTA50 / QSK50	3047665
286	WATER PUMP BEARING	3003354
287	WATER PUMP BEARING – KTA38 / QSK38 / QSK60 / QSK95 / KTA50	S16069
288	PLUNGER – KTA38 / QSK38 / KTA50 / QSK50	3627927
289	HEXAGON FLANGE NUT – KTA19 / QSK19 / KTA50 / QSK50	3632305
290	INJECTOR AND VALVE ADJUSTMENT KIT – K19 / K38 / K50	3822575
291	OFFSET WOODRUFF KEY – V504 / V555 / V903 / KTA19 / QSK19 / KTA50 / QSK50	200708
292	WATER PUMP IMPELLER – KTA50 / QSK50 series	3050454
293	PLAIN HOSE – KTA19 / QSK19 / KTA50 / QSK50 / KTA38 / QSK38	60985
294	PLAIN HOSE – KTA19 / QSK19 / KTA50 / QSK50 / KTA38 / QSK38	3630125
295	PLAIN HOSE	3049565
296	HUMP HOSE	4080609
297	HUMP HOSE – KTA19 / QSK19 / KTA50 / QSK50	3634116
298	HUMP HOSE	3636437
299	FLEXIBLE HOSE – KTA38 / QSK38 / KTA50 / QSK50	3176571
300	FLEXIBLE HOSE – KTA38 / QSK38 / KTA50 / QSK50	3176576
301	FLEXIBLE HOSE – KTA50 / QSK50	3634396
302	FLEXIBLE HOSE – KTA50 / QSK50 / VTA Series	3635033
303	FLEXIBLE HOSE	3632028
304	FLEXIBLE HOSE – KTA38 / QSK38 / KTA50 / QSK50	3627910
305	FLEXIBLE HOSE – KTA50 / QSK50	3634749
306	FLEXIBLE HOSE – KTA50 / QSK50	3635032
307	FLEXIBLE HOSE – KTA50 / QSK50	3634390

308	FLEXIBLE HOSE – KTA50 / QSK50	3632026
309	FLEXIBLE HOSE – KTA38 / QSK38 / KTA50 / QSK50	3630864
310	FLEXIBLE HOSE – KTA38 / QSK38 / KTA50 / QSK50	3963454
311	WIRING HARNESS – KTA38 / QSK38 / QSK50	3629161
312	WATER HEADER COVER GASKET	3637727
313	EXHAUST OUTLET CONNECTION GASKET – KTA50 / QSK50	3055695
314	AFTERCOOLER CORE – QSK50	3626714
315	EXHAUST CLAMP – KTA19 / QSK19 / KTA38 / QSK38 / KTA50	4936174
316	EXHAUST CLAMP – KTA19 / QSK19 / KTA50 / QSK51	3089765
317	EXHAUST CLAMP – KTA19 / QSK19 / KTA50 / QSK50	3029631
318	ETR FUEL CONTROL ACTUATOR – KTA50	3408325
319	ETR FUEL CONTROL ACTUATOR – KTA50	3330600
320	CYLINDER BLOCK – QSK50	3178803
321	PLUNGER – KTA38 / QSK38 / KTA50 / QSK50	3021618
322	BYPASS VALVE BODY – KTA / QSK	3028552
323	CYLINDER BLOCK – QSK50	4955242
324	FUEL TRANSFER PUMP – QSK50	3647015
325	SEA WATER PUMP GEAR – KTA19 / QSK19 / KTA38 / QSK38 / KTA50	3008841