

GUANGZHOU HAWKS AUTOPARTS CO.,LTD

No.8 Xicheng Road,Renhe Town,Baiyun District, Guangzhou City, Guangdong Province

[Web:www.hawksparts.com](http://www.hawksparts.com) [E-mail:sales@hawksparts.com](mailto:sales@hawksparts.com)[Contact person:Hawks Sale Team](mailto:sales@hawksparts.com) [Mob:+86 18027472559](tel:+8618027472559)**Cummins QSK60 and QSK95 Engine Overhaul Parts**

No.	Cummins QSK60 and QSK95 Overhaul Gasket Sets Components	Part No.
1	GASKET SET – QUADRANT AFTERCOOLER – QSK60	4089201
2	GASKET SET – QUADRANT AFTERCOOLER – QSK60	4955369
3	GASKET SET – QSK45 / QSK60 (LOWER PUMP)	4089307
4	GASKET SET – QSK45 / QSK60 (LOWER FUEL)	4089308
5	LOWER ENGINE GASKET SET – QSK60 / QSK95	4089874
6	COOLING SYSTEM GASKET SET – QSK60	4089509
7	GASKET SET – COOLING SYSTEM GASKET SET – QSK45 / QSK60	4089202
8	LOWER OIL PAN GASKET SET – QSK60	4956000
	Cummins QSK60 and QSK95 Turbochargers	
9	TURBOCHARGER – QSK60 / QSK95 (HX83, WATER COOLED)	4089581
10	TURBOCHARGER – QSK60 / QSK95 (HX83, WATER COOLED)	4090064
11	TURBOCHARGER – QSK60 / QSK95 (HX83, WATER COOLED)	4089729
12	TURBOCHARGER – QSK60 / QSK95 (HX83, WATER COOLED)	4089296
13	TURBOCHARGER – QSK60 / QSK95 (HX82, DRY)	3800499
14	TURBOCHARGER – QSK60 / QSK95 (HX82, DRY)	4089498
15	TURBOCHARGER – QSK60 / QSK95 (HX60)	4089808
16	TURBOCHARGER – QSK60 / QSK95 (HX60)	3800830
17	TURBOCHARGER – QSK60 / QSK95 (HX83, WATER COOLED)	4024975
18	TURBOCHARGER – QSK60 / QSK95 (HX82, DRY)	4089499
19	TURBOCHARGER – QSK60 / QSK95 (HX82, DRY)	4955914
20	TURBOCHARGER – QSK60 / QSK95 (HX82, DRY)	4955791
21	TURBOCHARGER – QSK60 / QSK95 (HX82, DRY)	4955294
22	TURBOCHARGER – QSK60 / QSK95 (HX82, DRY)	4955289
23	TURBOCHARGER – QSK60 / QSK95 (HX83, WATER COOLED)	4955689
24	TURBOCHARGER – QSK60 / QSK95 (HX82, WATER COOLED)	4025354
25	TURBOCHARGER – QSK60 / QSK95 (HX82, DRY)	4089935
26	TURBOCHARGER KIT – QSK60 / QSK95	2882097
27	TURBOCHARGER – QSK60 / QSK95 (HX83, WATER COOLED)	4089730
28	TURBOCHARGER – QSK60 / QSK95 (HX82, DRY)	4955249

29	TURBOCHARGER – QSK60 / QSK95 (HE851)	5321619
30	TURBOCHARGER – QSK60 / QSK95 (HE851)	5321617
31	TURBOCHARGER – QSK60 / QSK95	5321612
	Cummins QSK60 and QSK95 Aftercoolers	
32	AFTERCOOLER CORE – QSK60 / QSK95	3641078
33	AFTERCOOLER CORE – QSK95	4100636
34	AFTERCOOLER – QSK60 / QSK95	3646235
	Cummins QSK60 and QSK95 Cylinder Head Gaskets	
35	CYLINDER HEAD GASKET SET – QSK60 / QSK95 (QUADRANT)	4376323
36	CYLINDER HEAD GASKET SET – QSK60 / QSK95 (QUADRANT)	4376326
37	CYLINDER HEAD – QSK60 / QSK95	3650878
38	CYLINDER HEAD GASKET SET – QSK60 (QUADRANT)	4089200
39	CYLINDER HEAD GASKET SET – QSK60 (QUADRANT)	4089508
40	CYLINDER HEAD GASKET SET – QSK60 (QUADRANT)	4955370
	Cummins QSK60 and QSK95 Valve Train Components	
41	EXHAUST VALVE – KTA19 / QSK19 / QSK60 / QSK95	3090469
42	PUSH ROD – QSK45 / QSK60 / QSK95	3410897
43	PUSH ROD – QSK60 / QSK95	4080240
44	INTAKE VALVE – QSK60 / QSK95	2881822
45	EXHAUST VALVE – KTA19 / QSK19 / QSK60 / QSK95	2881813
46	INTAKE VALVE KIT – KTA19 / QSK19 / QSK45 / QSK60 / QSK95	2881810
47	EXHAUST VALVE KIT – QSK45 / QSK60 / QSK95	2881811
48	INTAKE VALVE KIT – KTA19 / QSK19 / QSK60 / QSK95	2881815
49	EXHAUST VALVE KIT – KTA19 / QSK19 / QSK60 / QSK95	2881812
	Cummins QSK60 and QSK95 Thermostats	
50	THERMOSTAT – QSK60	3651379
51	THERMOSTAT – KTA38 / QSK38 / QSK45 / QSK50 / QSK60	3055663
52	THERMOSTAT – QSK60 / QSK78 / QSK95	4085995
53	THERMOSTAT – KTA38 / QSK38 / QSK60 / QSK95	4014541
54	THERMOSTAT – QSK60 / QSK95	4014540
55	THERMOSTAT – KTA / QSK (176°F, NON VENTED)	3629205
56	THERMOSTAT – QSK60 / QSK95	3645857
57	REGULATOR – KTA38 / QSK38 / QSK45 / QSK50 / QSK60	3639983
	Cummins QSK60 and QSK95 Repair Kits	

58	WATER PUMP REPAIR KIT – QSK45 / QSK60 / QSK95 (MINOR)	3803284
59	WATER PUMP REPAIR KIT – KTA38 / KTA50 / QSK38 / QSK45	4085922
60	RAW WATER PUMP REPAIR KIT – QSK60 / QSK95	4919913
61	RAW WATER PUMP REPAIR KIT – QSK60 / QSK95	4919953
62	WATER PUMP – QSK60 / QSK95	4097835
63	WATER PUMP KIT – QSK45 / QSK60 / QSK95	4376121
	Cummins QSK60 and QSK95 Heat Exchangers	
64	HEAT EXCHANGER – QSK95	2867223
65	HEAT EXCHANGER PLATE GASKET – QSK60 (END PLATE)	4916121
66	HEAT EXCHANGER PLATE GASKET – QSK60 (B PLATE)	4916120
67	HEAT EXCHANGER PLATE GASKET – QSK60 (A PLATE)	4916119
68	HEAT EXCHANGER PLATE – QSK60 (B PLATE)	4916118
69	HEAT EXCHANGER PLATE – QSK60 (B PLATE)	4916115
70	HEAT EXCHANGER PLATE – QSK60 (B PLATE)	4916113
71	HEAT EXCHANGER PLATE – QSK60 (B PLATE)	4916116
72	HEAT EXCHANGER PLATE – QSK60 (A PLATE)	4916111
73	HEAT EXCHANGER PLATE – QSK60 (A PLATE)	4916114
74	HEAT EXCHANGER PLATE – QSK60 (A PLATE)	4916112
75	HEAT EXCHANGER PLATE – QSK60 (A PLATE)	4916117
76	HEAT EXCHANGER – QSK95	4099163
	Cummins QSK60 and QSK95 Fuel Filters	
77	FUEL/WATER SEPARATOR FILTER (SPIN-ON)	FS1006
78	FUEL/WATER SEPARATOR FILTER	FS1013
79	FUEL/WATER SEPARATOR FILTER	FS19870
	Cummins QSK60 and QSK95 Camshaft Components	
80	CAMSHAFT – QSK60 / QSK95 (LEFT BANK)	3411289
81	CAMSHAFT – QSK60 / QSK95	4001269
82	CAMSHAFT – QSK60 / QSK95	4001270
83	CAMSHAFT – QSK60	4017569
84	CAMSHAFT – QSK60	4017570
85	CAMSHAFT – QSK60 / QSK95	3411290
86	CAMSHAFT – QSK60 / QSK95	3643246
87	CAMSHAFT – QSK60 / QSK95	3643247
	Cummins QSK60 and QSK95 Piston Kits	

88	PISTON KIT – QSK60 / QSK95	4955326
89	PISTON KIT – QSK45 / QSK60 / QSK95	4955782
90	PISTON KIT – QSK60 / QSK95	4089506
91	PISTON KIT – QSK45 / QSK60 / QSK95	4309253
	Cummins QSK60 and QSK95 Piston Ring Sets	
92	PISTON RING SET – KTA19 / QSK19 / QSK50 / QSK60 / QSK95	4309503
93	PISTON RING SET – QSK45 / QSK60 / QSK95	4309254
94	PISTON RING SET – QSK60 / QSK95	4955327
95	PISTON RING SET – QSK45 / QSK60 / QSK95	4089247
96	PISTON RING SET – QSK60 / QSK95	4956091
	Cummins QSK60 and QSK95 Connecting Rods	
97	CONNECTING ROD – QSK60 / QSK95	3644677
98	CONNECTING ROD – QSK60 / QSK95	3644676
99	CONNECTING ROD – QSK60 / QSK95	4916318
100	CONNECTING ROD – QSK45 / QSK60 / QSK95	3635126
	Cummins QSK60 and QSK95 Connecting Rod Bearings	
101	CONNECTING ROD BEARING – QSK60 / QSK95 (STANDARD)	3647654
102	CONNECTING ROD BEARING – QSK60 / QSK95 (STANDARD)	3647655
103	CONNECTING ROD BEARING – QSK60 / QSK95 (STANDARD)	3636495
104	CONNECTING ROD BEARING – QSK60 / QSK95 (.25 MM)	3636496
	Cummins QSK60 and QSK95 Crankshaft Bearings and Seals	
105	CRANKSHAFT – QSK60	3647093
106	MAIN BEARING SET – QSK60 / QSK95 (.030)	4024795
107	MAIN BEARING SET – QSK60 / QSK95 (STANDARD)	4090025
108	MAIN BEARING SET – QSK60 / QSK95 (STANDARD)	4024792
109	MAIN BEARING SET – QSK60 / QSK95 (.020)	4024794
110	MAIN BEARING – QSK60 / QSK95 (.010)	4024793
	Cummins QSK60 and QSK95 Vibration Dampers	
111	VIBRATION DAMPER – QSK60 / QSK78 / QSK95 (VISCOUS)	3089126
112	VIBRATION DAMPER – KTA50 / QSK38 / QSK50 / QSK60	3089627
113	VIBRATION DAMPER – QSK60 (VISCOUS)	4007034
114	VIBRATION DAMPER – QSK60 / QSK95 (VISCOUS)	4007035
	Cummins QSK60 and QSK95 Belts	
115	BELT TENSIONER – QSK45 / QSK60 / QSK78 / QSK95	4086084

116	RIBBED V-BELT – QSK60 / QSK95	3171130
117	RIBBED V-BELT – QSK45 / QSK60 / QSK95	4016021
118	RIBBED V-BELT – QSK60 / QSK95	4066750
119	RIBBED V-BELT – QSK60 / QSK95	4016043
120	RIBBED V-BELT – QSK45 / QSK60 / QSK95	4015784
	Cummins QSK60 and QSK95 Piston Cooling Nozzles	
121	PISTON COOLING NOZZLE – QSK60 / QSK95	3651209
122	PISTON COOLING NOZZLE – QSK60 / QSK95	3640536
123	PISTON COOLING NOZZLE – QSK45 / QSK60 / QSK95	4086586
124	PISTON COOLING NOZZLE – QSK45 / QSK60 / QSK95	4100577
125	PISTON COOLING NOZZLE – QSK60 / QSK95	4955917
	Cummins QSK60 and QSK95 Lubricating Primers	
126	ENGINE LUBRICATING PRIMER – KTA50 / QSK38 / QSK50	3630004
127	ENGINE LUBRICATING PRIMER – KTA50 / QSK38 / QSK50	3628997
128	ENGINE LUBRICATING PRIMER – KTA50 / QSK38 / QSK50	3637969
129	ENGINE LUBRICATING PRIMER – KTA50 / QSK38 / QSK50	3628965
	Cummins QSK60 and QSK95 Exhaust Manifolds	
130	EXHAUST MANIFOLD – QSK60 / QSK95	2881349
131	EXHAUST MANIFOLD – QSK60 / QSK95	3642650
132	EXHAUST MANIFOLD – QSK60 / QSK95	4014639
133	EXHAUST MANIFOLD – QSK60 / QSK95	4924321
134	EXHAUST MANIFOLD – QSK60 / QSK95	4065900
135	EXHAUST MANIFOLD – QSK60 / QSK95	4065896
136	EXHAUST MANIFOLD – QSK60 / QSK95	4098277
137	EXHAUST MANIFOLD – QSK60 / QSK95	4098275
138	EXHAUST MANIFOLD – QSK60 / QSK95	3636245
139	EXHAUST MANIFOLD BELLOWS – QSK60 / QSK95 / KTA38 / QSK38	3968643
140	EXHAUST MANIFOLD BELLOWS – QSK60 / QSK95 / QSK45	4080141
141	EXHAUST MANIFOLD – QSK60 / QSK95	3643262
142	EXHAUST MANIFOLD – QSK60 / QSK95	3643261
143	EXHAUST MANIFOLD – QSK60 / QSK95	3642648
144	EXHAUST MANIFOLD – QSK60 / QSK95	3642651
145	EXHAUST MANIFOLD – QSK60 / QSK95	3642649
146	EXHAUST MANIFOLD – QSK60 / QSK95	3642653

147	EXHAUST MANIFOLD – QSK60 / QSK95	3642652
148	EXHAUST MANIFOLD – QSK60 / QSK95	3642654
149	EXHAUST MANIFOLD – QSK60 / QSK95	3642656
150	EXHAUST MANIFOLD – QSK60 / QSK95	3642657
151	EXHAUST MANIFOLD – QSK60 / QSK95	3643258
152	EXHAUST MANIFOLD – QSK60 / QSK95	3643360
153	EXHAUST MANIFOLD – QSK60 / QSK95	4100728
154	EXHAUST MANIFOLD – QSK60 / QSK95	4100730
155	EXHAUST MANIFOLD – QSK60 / QSK95	4100732
156	EXHAUST MANIFOLD – KTA38 / QSK38 / QSK60 / QSK95	4014641
157	EXHAUST MANIFOLD – QSK60 / QSK95	2881347
158	EXHAUST MANIFOLD – KTA38 / QSK38 / QSK60 / QSK95	4014642
159	EXHAUST MANIFOLD – QSK60 / QSK95	2881348
160	EXHAUST MANIFOLD – QSK60 / QSK95	4014640
161	EXHAUST MANIFOLD – QSK60 / QSK95	4014638
	Cummins QSK60 and QSK95 Senders and Switches	
162	MAGNETIC SWITCH – QSK60 / QSK95	4927870
163	PRESSURE SENSOR – QSK45 / QSK60 / QSK78 / QSK95	4306987
164	PRESSURE SENSOR – QSK45 / QSK60 / QSK95	4306988
165	GEAR OIL PRESSURE SENSOR	4306990
166	POSITION SENSOR – KTA19 / QSK19 / QSK60 / QSK95	4326595
167	TEMPERATURE SENSOR – QSK50 / QSK60 / QSK95	4358666
168	PRESSURE SENSOR – QSK60 / QSK78 / QSK95	2872371
169	PRESSURE SENSOR – QSK60 / QSK78 / QSK95	2872883
170	POSITION SENSOR – QSK23 / QSK50 / QSK60 / QSK95	4307676
171	PRESSURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38	4927797
172	SPEED SWITCH – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	4003714
173	SPEED SWITCH – QSK60 / QSK95 (12 V)	4927266
174	RELAY SWITCH – KTA38 / QSK38 / QSK50 / QSK45	3633715
175	RELAY SWITCH – QSK45 / QSK60 / QSK78 / QSK95	4065468
176	PRESSURE SWITCH – QSK60 / QSK95	4099167
177	PRESSURE SWITCH – QSK45 / QSK60 / QSK78 / QSK95	4101287
178	PRESSURE SWITCH – KTA19 / KTA38 / QSK19 / QSK38	4927365
179	PRESSURE SWITCH – QSK45 / QSK60 / QSK95	4984638

180	MAGNETIC SWITCH – KTA38 / QSK38 / QSK45 / QSK50	4951864
181	MASTER SWITCH – QSK60 / QSK95	4927263
182	TEMPERATURE SENSOR – QSK45 / QSK60 / QSK95	3408538
183	TEMPERATURE SENSOR – QSK45 / QSK60 / QSK95	3408544
184	TEMPERATURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38	4903202
185	TEMPERATURE SENSOR – QSK60 / QSK95	4951944
186	SPEED SENSOR – KTA38 / QSK38 / QSK50 / QSK60 / QSK95	4041599
187	PRESSURE SENSOR – QSK50 / QSK60 / QSK95	4927802
188	PRESSURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38	4964102
189	PRESSURE SENSOR – QSK45 / QSK50 / QSK60 / QSK95 / QST30	4088734
190	PRESSURE SENSOR – QSK60 / QSK95	4099172
191	PRESSURE SENSOR – L10 / M11 / KTA19 / QSK19 / QSK60	4099173
192	PRESSURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	3408517
193	PRESSURE SENSOR – QSK45 / QSK60 / QSK95 / QSV81 / QSV91	3408558
194	PRESSURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	3408602
195	FLUID LEVEL SENSOR – KTA19 / QSK19 / QSK50 / QSV81	3096793
196	SPEED SWITCH – QSK60 / QSK95 (12 V)	4927267
197	MAGNETIC SWITCH – QSK60 / QSK95	2886477
198	SWITCH	4963952
199	TEMPERATURE SENSOR – QSK60 / QSK95	4954450
200	TEMPERATURE SENSOR – QSK60 / QSK95	3642537
201	PRESSURE SENSOR	2872254
202	PUSH BUTTON SWITCH – KTA38 / QSK38 / QSK50 / QSK60 / QSK95	5254228
203	RELAY SWITCH – KTA38 / QSK38 / QSK45 / QSK60 / QSK95	4951860
204	TEMPERATURE SENSOR – QSK45 / QSK60 / QSK95	3645834
205	TEMPERATURE SENSOR – QSK45 / QSK60 / QSK95	3645835
206	FLUID LEVEL SENSOR – QSK60 / QSK95	4917680
207	TEMPERATURE SWITCH	4327016
208	TEMPERATURE SWITCH	4327019
	Parts for Cummins QSK60 and QSK95 Engines	
209	GASKET SET – QSK60 (TURBO AND INTERCOOLER)	4089203
210	CYLINDER LINER KIT – QSK60 / QSK45 (STANDARD)	4089143
211	WATER PUMP BEARING – KTA38 / QSK38 / QSK60 / QSK95 / KTA50	S16069
212	STARTER – QSK45 / QSK60 / QSK95 (AIR)	4100563

213	PLAIN HOSE – QSK60 / QSK95	3636448
214	PLAIN HOSE	3049565
215	FLEXIBLE HOSE – QSK60 / QSK95	3410941
216	THERMOSTAT HOUSING GASKET – QSK60 / QSK95	4066827
217	ALTERNATOR – QSK45 / QSK60 / QSK78 / QSK95	4101372
218	WATER PUMP ADAPTER O-RING – QSK45 / QSK60 / QSK95	4016906
219	ETR FUEL CONTROL ACTUATOR – QSK95 / QSK23	3347907
220	ETR FUEL CONTROL ACTUATOR – VTA SERIES / QSK60 / QSK95	3330602
221	BYPASS VALVE BODY – KTA / QSK	3028552
222	CYLINDER HEAD LEAK TEST KIT – KTA19 / QSK19 / QSK23 / QSK45 / QSK60 / QSK95	3164341
223	OIL COOLER CORE – QSK45 / QSK60 / QSK95	3641960
224	OIL PUMP – QSK60 / QSK95	3644518
225	fuel pump – QSK60 / QSK95 (RIGHT HAND)	2897671
226	INTERCOOLER CORE – QSK95	3638821
227	OIL COOLER – QSK95	4918026
228	ALTERNATOR – QSK45 / QSK60 / QSK95	3332213
229	OIL PUMP – QSK60 / QSK78 / QSK95	3644516
230	FUEL INJECTOR	4326784